Bahama—PVC

Shutter Specifications



PVC solid maintenance free synthetic

Finishes Available:

Unfinished—ready to paint Factory Painted—9 standard, unlimited custom colors

Assembly:

All solid components Joints secured with polyurethane exterior glue and 3 ½" threaded screw

Hardware:

Info and links to endorsed provider on web site

Pricing & Ordering:

Online at shutterland.com



Shown with one vertical sub-Stile

Measure Bahama

Install Bahama

SHUTTER SIZES	Widths: 16" - 60" (1/4" increments) Heights: 18" - 95" (1/4" increments)				
LOUVER SIZES	1 5/8" louvers 5/16" thick Spaced on 1 5/16" centers Fixed 27° angle with 1/4" space between louvers				
TOP RAIL	2 3/4" on front, 2 1/2" on back Rabbeted to reduce gap between rail and top louver				
DIVIDER RAIL(s) one or two	2 1/2" on front and back Required over 90" height Rabbeted to reduce gap between rail and louvers Location measured from bottom of shutter to center of divider				
BOTTOM RAIL dependent on shutter height	2 7/8" – 4 3/16" on front 3 1/8" – 4 7/16" on back Rabbeted to reduce gap between rail and bottom louver				
SIDE STILES	2 7/16" wide Metal support strips inserted in stiles on shutters over 84" in height— visible on back				
SUB-STILE(s)	2 7/16" wide Number allowed determined by shutter width				
THICKNESS	1 1/4" thick				



1-800-483-5028

Measuring Worksheet

Bahama Shutters

Use this form to prepare an order to place online at shutterland.com. Follow the measuring instructions provided online to measure accurately and receive the right shutter fit for your windows.

SHUTTER DETAILS

Style	🗌 Bahama / Bermuda	Finish	 Unfinished, Paint Grade Unfinished, Stain Grade Factory Primed Factory Painted 		
			🛛 Black	🗌 White	
Material	 □ Red Grandis □ PVC □ Cedar □ Mahogany 	rmsn	 Chrome Green Charcoal Slate Country Redwood Black Forest Green 	 Cottage Red Hamilton Blue Tudor Brown Custom Color 	

	Window Location (for your reference only)	Shutter Quantity (NOT Pairs)	Shutter Width	Shutter Height	Vertical Sub-Stile (# allowed determined by shutter width)	Divider Rail (measure from bottom of shutter to center of divider)
1						
2						
3						
4						
5						
6						
7						
8						
9						
10						



1-800-483-5028